




## amiando quick start manual for Voyager BT


1. Unpack the scanner and the cradle and plug the one end of the wire into the cradle and the other end into the USB port of your computer. Furthermore plug the power supply unit into the wall socket and connect it with the cradle.
2. Charge the scanner battery 2.5 hours.






3. Connect the scanner with the cradle by scanning the bar code printed on the cradle.

Scan Bluetooth  
Address Code



4. Wait 10 seconds until the blue LED light on the station stops blinking as well as the LED light on the scanner. Both LEDs should gleam blue constantly now
5. Start EasyEntry, log in and select an event. Select the scanner as reader and click in the field below.



Now you can start letting people in!